

# Koason BENZ new C /GLC/V (2015-2018) INSTALLATION GUIDANCE



1. Use crowbar to prize up the arm box silver trim.

2. Unscrew the two screws on Armrest box.



3. Pull up armrest panel slowly, pls be careful

4. Unplug car plugs



5. Prize up central speaker net cover

6. Unscrew the screws on speaker

7. Pull out car monitor slowly

8. Unscrew the screws on CD



9. Unplug cables behind monitor

10. Car cables behind CD

11. Android cables put in car

12. Android GPS antenna passes through the car



13. Android USB passes to armrest box

14. Car LVDS plug to android lvds

15. Use original two screws fix on android monitor and plug cables

16. Plug USB audio box to power cable and plug in car usb



17. Connect Android plug to car CD, switch fiber cable from original socket into android socket, original plug to android other end

18. After wires are connected, power up car and check android and original screen if it is showing normal and see if it has sound or not in music mode, check reverse, joystick.

19. Plug all cables back, install panel and cover back.

20. Installation finish.