

Koason BENZ E class W212 INSTALLATION GUIDANCE



1. Original radio



2. Use crowbar to prize up the monitor panel



3. Remove screen fix screws



4. Open glove box, pull down the buckle



5. Use small slotted screwdriver, move the Air outlet buckle to the middle



6. Pry the vent panel



7. Pry the middle panel



8. Unplug screws on CD, take the CD out little by little



9. Plug LVDS from original monitor to android lvds, NTG4.0 need LVDS switch box



10. Plug android cable to CD



11. Switch fiber cable from original female socket into android male socket



12. NTG5.0: plug USB audio box on power cable to car USB port; NTG4.0/4.5/4.7: plug AUX/AMI into car



13. Install back CD, Put our plastic base on



14. Installation finish.