

Koason BMW E90 INSTALLATION GUIDANCE



1. Take out the paster from the BOX (2PCS)



2. Remove the bottom sticker.



3. Stick as picture show



4. Remove the top sticker.



5. Remove the sticker.



6. Align and Overlap with GREEN line.



7. Still well as picture show



8 Cut along RED Line.



9. After cutting, effect picture.

Installation Guide

(Fits for BMW E90 (2005-2012/Original no Monitor))



10. Original dashboard



11. Stick the paper in original dashboard and cut.



12. Above picture is after cutting by a knife.



13. Pry loose and take out the decoration strip.



14. Pry loose the air-conditioner panel



15. Remove the screws.



16. Pull out the original power harness



17. Pry loose the decoration strip and take it out.



18. Take out the storage box



19. Install well the iDrive button



20. iDrive effect photo after installation



21. Remove the screw in the hole we cut just now.



22. Locked the Metal holder with Android screen.



23. Plug well the android power harness, and USB cable.



24. Plug well the GPS antenna.



25. Locked the screen to fix it well.



26. Plug the optical fiber into Android power harness.



27. Plug Original power harness with Android



28. Assemble well again.



29. Effect photo after installation well.